



meteobot®

Appendix Nr.2

USER MANUAL

Thank you for buying Meteobot®!

This user manual contains instructions for installation, correct operation and de-installation of Meteobot® weather stations.

Please read the instructions carefully before you begin – the product warranty depends on the correct installation and operation.

22 May 2019
Version 1.4

Prointegra Ltd.
Bulgaria, Varna 9009
2, Todor Penev str.
+359 884 833 780
tech@meteobot.com
www.meteobot.com

Table of Contents

1	Preparation.....	3
1.1	What's in the box?.....	3
1.2	General Overview	4
1.3	Before you start the installation.....	5
2	Where to place the weather station?	6
2.1	Sensor for temperature, relative humidity and air pressure.....	6
2.2	Wind speed sensor	6
2.3	Rain sensor	6
2.4	Solar panel.....	6
3	Installation.....	7
3.1	Pole	7
3.2	Box with electronic circuit board.....	7
3.3	Sensor for temperature, relative humidity and air pressure.....	8
3.4	Solar panel.....	8
3.5	Rain sensor	9
3.6	Wind speed sensor	9
3.7	Soil temperature sensor	10
3.8	Soil moisture sensor	10
3.9	Leaf wetness sensor	12
3.10	Connecting the cables	12
3.11	Cable connection scheme.....	13
4	Diagnostics	14
4.1	Initial startup	14
4.2	Data transmission	14
4.3	No GSM coverage	14
4.4	No connection to the server	14
5	Receiving data from the weather station.....	15
5.1	Install the mobile application	15
5.2	Registering the weather station	15
5.3	Data transfer frequency	15
6	Maintenance	16
7	Troubleshooting	17
7.1	Battery not charging	17
7.2	The weather station does not send data.....	18
7.3	Missing or incorrect sensor data	18
8	Uninstallation	19
8.1	Uninstalling the weather station	19
8.2	Uninstalling a sensor	19
8.3	Replacing the battery	19
8.4	Replacing the solar panel	20
9	Technical specifications.....	21
10	Protecting the environment.....	22
10.1	Disposal	22
10.2	Battery information	22

1 Preparation

1.1 What's in the box?



No	Component	Meteobot Pro	Meteobot Mini
1	Box with electronic circuit board	✓	✓
2	Rain sensor	✓	✓
3	Wind speed sensor	✓	
4	Solar panel	✓	✓
5	Air temperature, relative humidity and air pressure sensor	✓	
6	Leaf wetness sensor	Depending on order	
7	Soil temperature sensor	✓	✓
8	Soil moisture sensor	✓	Depending on order
9	Battery	✓	✓

1.2 General Overview

